User guide Arena

LEAFIELD recycling products



Cleaning Products should be rinsed with clean water and then washed with a mild detergent solution using a bristle brush or sponge. Care should be taken not to apply undue pressure that may damage labels. Flush clean with water after washing. Non heated pressure washer can be used at no closer the 400mm away from the unit. The Pressure should be no more than 100 Bar.



Quality Standards All Leafield Environmental products are certificated to BS EN ISO









PPE Always wear appropriate PPE equipment and follow safety guidelines.



ToolsPlastic key as supplied

Sack removal and replacement



Remove the bin lid by lifting the front end tilting backwards to free from the back locators.



Remove the sack



Insert the sack and pull tight around the back locators.













Sack removal and replacement



Ensure the sack is kept taught when fitting around the front edge of the bin



Engage the rear locators first under the lip of the body before closing.







