User guide

Classic & Mini Classic



LEAFIELD litter products



Cleaning Products should be rinsed with clean water and then washed with a mild detergent solution using a bristle brush or sponge. Care should be taken not to apply undue pressure that may damage labels. Flush clean with water after washing. Non heated pressure washer can be used at no closer the 400mm away from the unit. The Pressure should be no more than 100 Bar.



Quality Standards All Leafield Environmental products are certificated to BS EN ISO










PPE Always wear appropriate PPE equipment and follow safety guidelines.



Tools

Plastic key as supplied



Unlocking and opening door



Insert key and turn clockwise until stop. Lock will pop out and release



Twist bin top anticlockwise until it stops.




Lift top upwards and off the bin.













Removing and replacing liner, engaging lock




Remove the liner and empty the waste.




Replace the empty liner and bin hood



Push in the plunge lock to engage and secure the lid











envinfo@leafieldenv.com



