User guidelines Leafield litter bins Envirobank split liner







Cleaning Products should be flushed with clean water and then washed with a mild detergent solution using a bristle brush or sponge. Care should be taken not to apply undue pressure that may damage labels. Flush clean with water after washing.



Quality Standards All Leafield Environmental products are certificated to BS EN ISO













PPE Always wear appropriate PPE equipment and follow safety guidelines.

Unlocking and opening door



Turn key clockwise until it stops, hold key in stop position



With key turned, grip under front panel and lift bin door upward until it stops. Remove key



Pivot the door open. Once opened the door will rest in the lifted position, on the moulded support

Envirobank can be supplied with either a single wheeled liner a split wheeled liner or sack retention



Removing and replacing liners



Grip wheeled liner using forward facing handle



Tilt liner away from bin body and roll free from bin and empty. Repeat removal process with second liner



Replace liners tilting away from bin body and rolling over lip on base ensuring handle is facing outwards

Locking door



Ensure both liners are flat on bin base



Push door closed



When at closed position door will drop down and engage lock automatically

Corsham, Wiltshire SN13 9UD



