User guidelines

A3 Signage





































Cleaning Products should be flushed with clean water and then washed with a mild detergent solution using a bristle brush or sponge. Care should be taken not to apply undue pressure that may damage labels. Flush clean with water after washing.



Tools No tools required.



Quality Standards All Leafield Environmental products are certificated to BS EN ISO









PPE Always wear appropriate PPE equipment and follow safety guidelines.

Unpackaging



Remove all of the product packaging.



Remove the lid to reveal the signage frame and poles that will be safely stowed away inside of the bin during transportation.



Carefully remove the protective film covering the acrylic screen.

Please Note: Leafield does not operate a refuse collection system. this must be arranged by the customer.



Fitting the poles



Slot each of the 10mm dia support rods into the moulded in signage holes. The holes are located towards the back of the bin body. Please ensure that the chamfered end is fitted into the hole (as shown above).

Fitting the sign



Ensuring that the acrylic signage display is facing forwards, line up the two moulded holes found on the underside edge of the sign with the 10mm support poles (as shown). Gently push downwards until located. **Please Note:** Do not force into place.

Fitting Poster



Twist the acrylic keeper left or right to allow the acrylic pannel to drop frowards. Insert the A3 poster before re-aligning the keeper back into its original postion as shown.









